

**SEIKO**

**INSTRUCTIONS**

**SEIKO**

HT012-1

**A. FEATURES**

1. Ascending Alarm
2. Repeating Snooze Alarm
3. Luminous Hands
4. Accurate Quartz Movement
5. Operated by a piece of "AAA" size battery

**B. TO START THE CLOCK**

Open the battery cover and insert a fresh, good quality "AAA" size battery into the battery compartment making sure the battery polarity is as indicated.

**C. TO SET TIME**

Turn the time set knob, at the back of 9-hour position, clockwise or counterclockwise until the desired time is obtained on the dial.

**D. TO SET THE ALARM**

Turn the alarm set knob, at the back of 3-hour position, clockwise or counterclockwise until the alarm hand indicates the required alarm time.

Slide the On/Off switch to the "ON" position. The alarm will now sound at the selected time.

**E. SNOOZE**

The alarm can be stopped by pressing the lens. It will repeat again four (4) minutes later. This snooze function can be repeated again and again.

**F. TO SILENCE THE ALARM**

To stop the Alarm/Snooze, slide the On/Off switch to the "OFF" position. The alarm sound will now stop.

For replacement of the batteries included in your new Seiko Clock, please use Alkaline type batteries, which will offer approximately 9 months of battery life. Depending on the item, the battery initially supplied may not have a battery life of 9 months.

If the clock does not operate, or steadily loses time, or if the alarm sounds abnormal, the battery is low and should be replaced.